

INDUSTRIAL FLUID SYSTEMS

Mobile Micro Filtration Oil Purification Cart

Typical applications

Hydraulic/Lube Systems 50 to 700 Gallons -Gear Boxes -CNC Machines -Stamping Presses -Servo Controlled Sys. Batch Recycling -High Speed Spindle Oil -Lube Oil -Hydraulic Oil -Transmission Fluid

Equipment Specifications

1.10GPM, 4.2L/M Process Flow Rate
1.2 kW Heater w/ Temperature Gauge
Electrical Control w/ "On" & "Off" Push Buttons
Power Requirement: 120V–15 Amps
2, 5 or 15 Micron Elements
High Pressure Alarm
High Temperature Alarm
10ft. Electrical Cord
10ft. Inlet & Outlet Hoses

Optional Features

Cycle Timer Remote Level Sensors Particle Counter Moisture Sensor

NIDHOTDIAL ELHID OVOTEMO

22200 Ryan Road Warren, MI 48091 Phone: 800-343-8106 Fax: 586-754-8284 www.industrialfluidsystems.com The Mobile Micro Filtration Oil Purification System is designed to keep your equipment running at maximum efficiency. Contaminated oil destroys bearings, seals, pumps and servo valves causing premature wear, down time and high maintenance costs. The Micro Filter removes solids, micro solids and small amounts of water extending the life of the oil and the equipment. The system runs on 120 volt, 15 amp power. Industrial Fluid Systems custom build a system to meet your requirements.





Model: PFC-1/2-F58NTZ-120-1.2KW




INDUSTRIAL FLUID SYSTEMS

Mobile Micro Filtration Oil Purification Cart







22200 Ryan Road Warren, MI 48091 Phone: 800-343-8106 Fax: 586-754-8284 www.industrialfluidsystems.com

INDUCTOINE ELLID OVOTEMO

BLACKSTONE	
(LABORATORIES)	

REPORT

OIL LAB NUMBER: E09947 UNIT ID: AFTER POLISHNG REPORT DATE: 4/20/2010 CLIENT ID: 1314 CODE: 1/319

PAYMENT: Verbal, Paul

	LABORATORI	10				,				
UNIT	AKE/MODEL: Hydr FUEL TYPE: ADDITIONAL INFO:	aulic System		OIL TYPE & GRADE: Mobil DTE 24 Hydraulic OIL USE INTERVAL:						
CLIENT	PAUL HAMPTONPHONE: (586) 754-8220INDUSTRIAL FLUID SYSTEMSFAX: (586) 754-828422200 RYAN RDALT PHONE:WARREN, MI 48091EMAIL: phampton@industrialfluidsystems.com									
COMMENTS	PAUL: Wear read low but we found a high amount of silicon in this oil. The ISO code is 12/11/18, which is fairly clean for a hydraulic oil. We suspect the silicon is harmless, and if you agree then we think this oil can stay in use.									
	MI/HR on Oil									
	MI/HR on Unit		UNIT /			UNIVERSAL				
	Sample Date	04/16/10	LOCATION AVERAGES			AVERAGES				
	Make Up Oil Added		AVERAGES							
N	ALUMINUM	0	0			0				
MILLION	CHROMIUM	0	0			0				
	IRON	1	15			6				
2	COPPER	1	46			8				
	LEAD	1	2			2				
	TIN	1	1			0				
TS	MOLYBDENUM	0	0			1				
	NICKEL	0	0			0				
Р	MANGANESE	0	0			0				
Ν	SILVER	0	0			0				
S	TITANIUM	0	0			0				
	POTASSIUM	0	3			0				
Ξ	BORON	1	5			6				
Ē	SILICON	20	8			4				
Η	SODIUM	1	6			5				
	CALCIUM	57	96			187				
	MAGNESIUM PHOSPHORUS	7 453	4			20 374				
	ZINC	453	446 590			412				
	BARIUM	4/4	1			13				
	DANION	1	Values Should Be*			15				
	SUS Viscosity @ 210°F	49.1	44-49							
	cSt Viscosity @ 100°C	7.00	5.4-7.3							
S	Flashpoint in °F	430	>405							
Ë	Fuel %	-								
	Antifreeze %	-				4				
÷	Water %	0.0	0.0			4				
PER						1				
ROPER	Insolubles %	0.0	<0.1			_				
PROPERTIES	Insolubles % TBN	0.0	<0.1			-				
PROPER	Insolubles %	0.0	<0.1			-				

416 E. PETTIT AVE. FORT WAYNE, IN 46806 (260) 744-2380 www.blackstone-labs.com ©COPYRIGHT BLACKSTONE LABORATORIES 2007 LIABILITY LIMITED TO COST OF ANALYSIS

BLACKSTONE
(LABORATORIES)

REPORT DATE: 4/20/2010 **CLIENT ID:** 1314 CODE: 1/319

OIL

REPORT

LAB NUMBER: E09946 UNIT ID: BEFORE POLISHNG PAYMENT: Verbal, Paul

UNIT	MAKE/MODEL: Hydraulic System OIL TYPE & GRADE: Mobil DTE 24 Hydraulic FUEL TYPE: OIL USE INTERVAL: ADDITIONAL INFO: OIL USE INTERVAL:										
CLIENT	PAUL HAMPTONPHONE: (586) 754-8220INDUSTRIAL FLUID SYSTEMSFAX: (586) 754-828422200 RYAN RDALT PHONE:WARREN, MI 48091EMAIL: phampton@industrialfluidsystems.com										
COMMENTS	PAUL: A lot of silicon was found in this sample. It doesn't appear to be abrasive, since wear is so low. The ISO code was 20/19/16 which is dirty for a hydraulic oil. You could try filtering this oil, but 0.3% insolubles is generally more than can be removed through filtration. Due to insolubles, this Mobil DTE oil should probably be changed.										
	MI/HR on Oil										
	MI/HR on Unit		UNIT / LOCATION						UNIVERSAL		
	Sample Date	04/16/10	AVERAGES						AVERAGES		
	Make Up Oil Added										
_											
0	ALUMINUM	0	0						0		
MILLION	CHROMIUM	0	0						0		
V	IRON	2	15						6		
ER	COPPER	2	46						8		
PE	LEAD TIN	2	2						0		
	MOLYBDENUM	0	0						1		
RTS	NICKEL	0	0						0		
PA	MANGANESE	0	0						0		
	SILVER	0	0						0		
N	TITANIUM	0	0						0		
EMENTS	POTASSIUM	0	3						0		
EN	BORON	13	5						6		
Σ	SILICON	26	8						4		
H	SODIUM	3	6						5		
	CALCIUM	73	96						187		
	MAGNESIUM	2	4						20		
	PHOSPHORUS	494	446						374		
	ZINC	496	590						412		
	BARIUM	3	1						13		
			Values Should Be*								
	CLIC Vicessity @ 040°E	47.0					1	1	1		
	SUS Viscosity @ 210°F cSt Viscosity @ 100°C	47.6	44-49								
	Flashpoint in °F	6.52 410	5.4-7.3 >405								
ß	Fiashpoint in F	410	~405								
PROPERTIES	Antifreeze %	-									
μ	Water %	0.0	0.0								
D	Insolubles %	0.0	<0.1					1			
PR	TBN	0.3	-0.1					1			
	TAN								1		
	ISO Code	20/19/16							1		
								1	1		

* THIS COLUMN APPLIES ONLY TO THE CURRENT SAMPLE

416 E. PETTIT AVE. FORT WAYNE, IN 46806 (260) 744-2380 www.blackstone-labs.com ©COPYRIGHT BLACKSTONE LABORATORIES 2007 LIABILITY LIMITED TO COST OF ANALYSIS